# TECHNICAL DATA SHEET





# PRODUCT DESCRIPTION

IMG<sup>®</sup> Foaming Engine Cleaner safely and effectively cleans all engine bay surfaces, including metal parts, plastic covers and components, rubber hoses and seals, and wiring harnesses.

# **FEATURES**

- Quickly penetrates and dissolves oil, grease, coolant, antifreeze and other common functional fluids
- Easy to use simply spray onto a cool engine and wash away with water
- · Leaves no residue

### **DIRECTIONS FOR USE**

Do NOT apply IMG® Foaming Engine Cleaner to a hot engine.

Use IMG® Foaming Engine Cleaner ONLY in a well-ventilated area.

- 1. Stop the engine and allow it to cool.
- 2. Remove the air filter from the engine.
- Cover the distributor, any exposed wires, and carburetor air inlet. On fuel-injected engines, there is no need to cover the injectors.
- 4. Shake the can well.
- Holding the can upright, about 12-24 inches away from the engine, spray IMG<sup>®</sup> Foaming Engine Cleaner directly onto the cool, dry engine.
- 6. Allow IMG<sup>®</sup> Foaming Engine Cleaner to soak into the dirt, grime, and grease deposits for about 10 to 15 minutes.
- 7. Thoroughly and carefully hose off the engine with water, taking care to avoid electrical components. Allow the engine to dry.
- Remove coverings from the distributor, wiring, carburetor and distributor and replace any components that were disconnected.
- Start the engine only after making sure that the cleaner has been completely removed.

Do NOT start the engine until all of the applied IMG<sup>®</sup> Foaming Engine Cleaner has been properly and completely rinsed from the engine bay.

# **COLOR**

White

#### SHIPPING INFORMATION

Barcode	Packaging	Net Volume
817830010020	Aerosol Can	17 fl.oz
Net Weight	Per Case	Case Weight
17 oz	12	15.8 lbs
Case Length	Case Width	Case Height
8.5"	11"	10"
Cases/Pallet*	Pallet Height*	Pallet Weight*
76	45.6"	1201 lbs

# STORAGE AND SHELF LIFE

Store in cool, dry location in unopened containers. Do not expose to heat, open flames, strong oxidizers or other sources of ignition. Do not puncture or incinerate container. Use only in a well-ventilated area. IMG® Foaming Engine Cleaner has a general shelf life of 5 years from the date of manufacture.

## NOTE

The contents of this document, including all data and descriptions, are provided strictly for informational purposes. While the information contained herein is believed to be reliable, IMG Chemicals Corporation cannot assume responsibility for variations and/or nonconforming results obtained or observed by other parties whose product use, environment, and methods are outside of our control.

IMG CHEMICALS CORPORATION DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE THAT MAY ARISE FROM THE USE OF IMG PRODUCTS. IMG CHEMICALS CORPORATION SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY FOR INCIDENTAL AND/OR CONSEQUENTIAL DAMAGES, INCLUDING LOST PROFITS.

